



Step-by-Step  
**Elegant  
 Chair**  
 WOOD magazine  
 May 2011

To ensure full-size patterns are correct size, your printer should be set to print at 100% (not fit to page). Measure full-size patterns to verify size.



INSIDE FACE  
**BACK LEG**  
 (left leg shown; right leg is mirror image)