

Cutting the cord, and then some

MODEL	PERFORMANCE RATINGS (1)							BLADE MOUNT (RIGHT, LEFT)	BRUSHLESS MOTOR? (YES, NO)	BATTERY (2)			MAX. CUTTING DEPTH, INCHES		SHOE		AUTOMATIC BLADE BRAKE? (YES, NO)	LED? (YES, NO)	STORAGE BAG OR CASE?	WEIGHT, LBS.-OZ. (WITH BATTERY)	WARRANTY, YEARS (3)		COUNTRY OF ASSEMBLY (4)	SELLING PRICE (5)	CONTACT INFORMATION
	PRIMARY			SECONDARY						AMP-HOUR RATING	CHARGE TIME, MINUTES	CHARGER OUTPUT, AMPS	BLADE AT 0°	BLADE AT 45°	BEVEL ANGLE RANGE (MIN./MAX.), DEGREES	BEVEL ANGLE STOPS, DEGREES					SAW	BATTERY PACKS			
	POWER	RUNTIME PER BATTERY CHARGE	RELIABILITY OF CUTLINE NOTCHES	EASE OF ADJUSTING BLADE DEPTH	COMFORT/EASE OF USE OF HANDLE AND TRIGGER	TOOL BALANCE	EASE OF TILTING SHOE																		
6½" SAWS																									
CRAFTSMAN CMCS500M1	C	C	C-	B	B	B	B	L	N	4	61	4	2 3/16	1 13/16	0-50	0	Y	N	NONE	7-6	3	3	C	\$140	888-331-4569, craftsman.com
DEWALT DCS391P1	B	C	B-	B	B	B	B+	L	N	5	84	4	2 1/8	1 3/8	0-50	0	Y	N	CASE	7-9	3	3	M	\$250	800-433-9258, dewalt.com
MAKITA XSH03T	A	A-	A-	B	A	A	B+	L	Y	5	52	9	2 1/4	1 11/16	0-50	0, 45	Y	Y	BAG	7-10	3	3	R	\$390	800-462-5482, makitatools.com
MAKITA XSH04RB	D+	D	A	A	A	A	C	R	Y	2	24	9	2 1/4	1 11/16	0-50	0, 45	Y	Y	BAG	6-12	3	3	U	\$300	800-462-5482, makitatools.com
METABO HPT C18DBALQ4	B	B+	A	A	B+	B	C-	R	Y	5*	33	8*	2 9/16	1 13/16	0-45	0	Y	Y	NONE	7-7	L	2*	C	\$200	800-829-4752, metabo-hpt.com
MILWAUKEE 2730-21	B+	B	B+	B	B	B	A-	L	Y	5	92	3	2 1/8	1 3/8	0-50	0	Y	Y	BAG	8-8	5	3	C	\$320	800-729-3878, milwaukeetool.com
PORTER-CABLE PCC660B	C-	B-	C-	B	C-	B	B	L	N	4*	102	2*	2 1/8	1 3/4	0-50	0	Y	N	NONE	7-5	3	3*	C	\$60	888-848-5175, portercable.com
RYOBI P507	B-	B	A-	A	C+	B	B-	L	N	4*	116	2*	2	1 1/16	0-56	0	N	N	NONE	6-13	3	3*	C	\$69	800-525-2579, ryobitools.com
SKIL CR5413-1A	B	B	B+	B	B+	A-	B	R	Y	4	49	6	2 3/8	1 11/16	0-50	0	Y	Y	NONE	8-0	5	2	C	\$190	877-754-5999, skil.com
WORX WX530L	C	D+	B	B	D	B	C	R	N	2	345	.4	2 1/8	1 3/8	0-50	0	Y	N	NONE	4-6	2	1	C	\$120	855-279-0505, worx.com
7¼" SAWS																									
BOSCH GKS18V-25GC	A	A	C	C	A	A	A	R	Y	6.3*	53	4*	2 1/2	1 7/8	0-50	0	Y	Y	NONE	11-7	3	2*	H	\$250	877-267-2499, boschtools.com
CRAFTSMAN CMCS550B	A	A-	A	B	A-	A	B+	R	Y	6*	92	4*	2 1/2	2	0-56	0, 22.5, 45	Y	Y	NONE	8-12	3	3*	C	\$130	888-331-4569, craftsman.com
DEWALT DCS570P1	A	A-	A	B	A	A	A-	R	Y	5	82	4	2 1/2	2	0-57	0, 22.5, 45	Y	Y	BAG	9-11	3	3	C	\$280	800-433-9258, dewalt.com
MILWAUKEE 2631-21	A-	A-	A-	B	B	A	A	R	Y	5	104	3	2 1/2	1 3/8	0-50	0, 50	Y	Y	BAG	9-5	5	3	C	\$280	800-729-3878, milwaukeetool.com
RIDGID R8654B	A	A-	C-	B	B	B-	A	R	Y	6*	73	6*	2 5/8	1 3/8	0-56	0, 15, 22.5, 30, 45	Y	Y	NONE	10-15	3†	3*†	C	\$170	866-539-1710, ridgidpowertools.com
RYOBI P508	A-	A	A-	A	C+	B	B	L	Y	6*	174	2*	2 3/8	1 13/16	0-56	0, 45	Y	Y	NONE	8-13	3	3*	C	\$119	800-525-2579, ryobitools.com

- A Excellent
B Good
C Fair
D Poor

2. (*) Batteries not included with saw

- (L) Lifetime
 (*) Batteries not included with saw
 (†) Lifetime service agreement upon registration

- (C) China
 (H) Hungary
 (M) Mexico
 (R) Romania
 (U) United States

5. Prices current at time of article production and do not include shipping, where applicable.