



2 INSTALLING THE MITER FENCES



Step 1

Draw a line across the base parallel to its front edge. Center the inside corner of a framing square on the kerf and rotate it until the same dimension on both legs of the square intersects the parallel line.



Step 2

Attach the right-hand fence along one leg of the framing square and the left face against the other.